


No. 79 Flashing Railroad Signal
Item No. 11-90030

Setup:

Connecting Your No. 79 Flashing Signal

Underside View of No. 79 Flashing Railroad Signal



Connect the terminals on the underside of the No. 79 Flashing Railroad Signal to the terminals of a lock-on or to the terminals of a track activation device.

Operation:

When power is applied to the No. 79 Flashing Railroad Signal, the underside light bulb will be illuminated and the signal light bulbs will flash.

CAUTION: Electrically Operated Product:

Recommended for Ages 14 and up. Not recommended for children under 14 years of age without adult supervision.

As with all electric products, precautions should be observed during handling and use to prevent electric shock.

WARNING: When using electrical products, basic safety precautions should be observed, including the following:

Read this manual thoroughly before using this device.

- M.T.H. recommends that all users and persons supervising use examine the hobby transformer and other electronic equipment periodically for conditions that may result in the risk of fire, electric shock, or injury to persons, such as damage to the primary cord, plug blades, housing, output jacks or other parts. In the event such conditions exist, the train set should not be used until properly repaired.
- Do not operate your layout unattended. Obstructed accessories or stalled trains may overheat, resulting in damage to your layout.
- This train set is intended for indoor use. Do not use if water is present. Serious injury or fatality may result.
- Do not operate the hobby transformer with damaged cord, plug, switches, buttons or case.

To obtain Warranty Service, please visit our website www.lionelcorporation.com