

Fast Food Restaurant

The classic lines of a typical fast food stand bring an authentic American look to any layout, from the mid-50s to today. With its sturdy ABS construction and easy-to-wire interior lighting, this timeless restaurant will find a permanent home in RailTownTM, just as it has in every American town.

CAUTION: ELECTRIC TOY:

Not recommended for children under 14 years of age without adult supervision. As with all electric products, precautions should be observed during handling and use to prevent electric shock.

WARNING: When using electrical products, basic safety precautions should be observed, including the following: Read this manual thoroughly before using this device.

- M.T.H. recommends that all users and persons supervising use examine the hobby transformer and other electronic equipment periodically for conditions that may result in the risk of fire, electric shock, or injury to persons, such as damage to the primary cord, plug blades, housing, output jacks or other parts. In the event such conditions exist, the train set should not be used until properly repaired.
- Do not operate your layout unattended. Obstructed accessories or stalled trains may overheat, resulting in damage to your layout.
- This train set is intended for indoor use. Do not use if water is present. Serious injury or fatality may result.
- Do not operate the hobby transformer with damaged cord, plug, switches, buttons or case.

PLEASE READ BEFORE USE AND SAVE www.mthtrains.com

WIRING INSTRUCTIONS

The lighting in the fast food stand can be powered via either track power or by a 9v battery. To set up the building's power, gently turn the restaurant upside down and prop it carefully on a soft surface, so you do not damage the decorated shell. *Caution: Because there are different light bulbs for track and battery power, you should choose which method you will use and not try to switch between the two. The 18v bulb has a white socket, and the 9v bulb has a grey socket.*

To wire for track power:

With the transformer turned off, connect the AC hot and AC ground wires from the transformer to the two connection ports indicated on the bottom of the base.

The restaurant will be delivered with an 18v bulb (with a white socket) installed, which is the appropriate bulb for track powered lighting. DO NOT ATTEMPT TO RUN FROM TRACK POWER IF THE 9v BULB (WITH A GREY SOCKET) IS INSTALLED.


Note: there is an on-off switch on the back side of the restaurant itself. Keep the switch pushed to the right/ on position when you operate from track power.


To run lights from a battery:

The restaurant will be delivered with an 18v bulb installed, which is the appropriate bulb for track powered lighting but will be underpowered if used with battery power. Replace the 18v bulb (as described on the next page) with the 9v bulb (with a grey socket) included in the packaging.

Remove the cover from the battery box and install a 9v battery as indicated.

If you power the lights with a battery, you will need to turn them on and off manually when you enjoy your layout. Flip the switch to the left for the on position and to the right for off.









Figure 2. Switch Located on Rear Right Corner of Building



Remove the cover from the battery box and install a 9v battery as shown.

Figure 3. Locations of Battery Door and Light Replacement Door

To replace the light bulb:

1. Unscrew the single small Philips screw located in the plate marked "Light Bulb Replacement."

2. Gently pull the plate straight out from the base, until the bulb has cleared the opening.

3. Gently pull the bulb out of its housing and pop the new bulb into place. 18v bulbs have a white socket; 9v bulbs have a grey socket.

4. Replace the plate and bulb and screw it back into place to secure it.

You can obtain replacement bulbs directly from the M.T.H. parts department (Order online: www.mth-railking.com, e-mail: parts@mth-railking.com,Fax: 410-423-0009, Phone: 410-381-2500, Mail: 7020 Columbia Gateway Drive, Columbia MD 21046-1532,).

Service & Warranty Information

How to Get Service Under the Terms of the Limited One-Year Warranty

When you suspect an item is defective, please check the operator's manual for standard operation and troubleshooting techniques that may correct the problem. Additional information may be found on the M.T.H. Website. Should you still require service, follow the instructions below to obtain warranty service.

First, e-mail, write, call or fax M.T.H. Electric Trains or a M.T.H. Authorized Service Center (ASC) in your area to obtain Repair Authorization. You can find the list of ASCs on the M.T.H. Website, www.mth-railking.com. Authorized Service Centers are required to make warranty repairs on items sold *only* from that store; all other repairs may-- or may not be done at the store's own discretion. If you did not purchase the item directly from the ASC, you will need to select a National Authorized Service Center (NASC) or contact M.T.H. Electric Trains directly. NASC Dealers are compensated by M.T.H. to perform warranty service for any customer whose repair qualifies for warranty service. A list of NASC retailers can be located on the M.T.H. Website or by calling 410-381-2580. Should the warranty no longer apply, you may choose either an ASC or NASC retailer to service your M.T.H. Product. A reasonable service fee will be charged.

CAUTION: Make sure the product is packed in its original factory packaging including its foam and plastic wrapping material to prevent damage to the merchandise. There is no need to return the entire set if only one of the components is in need of repair *unless otherwise instructed by the Service Center.* The shipment must be prepaid and we recommend that it be insured. A cover letter including your name, address, daytime phone number, e-mail address (if available), Return Authorization number (if required by the service center, a copy of your sales receipt and a full description of the problem must be included to facilitate the repairs. Please include the description regardless of whether you discussed the problem with a service technician when contacting the Service Center for your Return Authorization.

Please make sure you have followed the instructions carefully before returning any merchandise for service. Authorized M.T.H. Service Centers are independently owned and operated and are not agents or representatives of M.T.H. Electric Trains. M.T.H. assumes no responsibility financial or otherwise, for material left in their possession, or work done, by privately owned M.T.H. Authorized Service Centers. If you need assistance at any time email MTH Service at <u>service@mth-railking.com</u>, or call 410 381-2580.

Limited One-Year Warranty

All M.T.H. products purchased from an Authorized M.T.H. Retailer are covered by this warranty. See our Website to identify an Authorized M.T.H. Retailer near you.

M.T.H. products are warrantied for one year from the date of purchase against defects in material or workmanship, excluding wear items such as light bulbs, pick-up rollers, batteries, smoke unit wicks, and traction tires. We will replace or credit (at our option) any defective item with a manufactured suggested retail price of \$279.95 or less (excluding all motive power and electronic items), if the item is returned to an M.T.H. Authorized Service Center (ASC) or M.T.H. National Authorized Service Center (NASC) within one year of the original date of purchase. For any item with an MSRP greater than \$279.95 (including all motive power and electronics), We will repair, replace or credit (at our option) the defective item without charge for the parts or labor, if the item is returned to an M.T.H. Authorized Service Center (ASC) or M.T.H. National Authorized Service Center (NASC) within one year of the original date of purchase. For any item with an difference of the defective item without charge for the parts or labor, if the item is returned to an M.T.H. Authorized Service Center (ASC) or M.T.H. National Authorized Service Center (NASC) within one year of the original date of purchase. This warranty does not cover damages caused by improper care, handling, or use. Transportation costs incurred by the customer to ship the product for warranty service are not covered under this warranty.

Items sent for repair must be accompanied by a return authorization number, a description of the problem, and a copy of the original sales receipt from an Authorized M.T.H. Retailer stating the date of purchase. If you are sending this product to an Authorized Service Center, contact that Center for their return authorization.

This warranty gives you specific legal rights, and you may have other rights that vary from state to state. Specific questions regarding the warranty may be forwarded to M.T.H. directly.

Service Department M.T.H. Electric Trains 7020 Columbia Gateway Drive Columbia MD 21046-1532 410-381-2580 service@mth-railking.com